

VERIFONE Vx510/Vx570 RESTAURANT

Customer Service: 800-201-0461
24-Hour Technical Support: 800-632-1888

SALE		
TERMINAL DISPLAY	ACTION	
Idle prompt	Swipe card or press F2 for sale.	
Password:	Key in the appropriate password and press ENTER .	
1= [Merchant 1]	Prev [F1] Next [F2] Slct [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .	
Swipe or enter account #:	Swipe card or key in the card number and press ENTER .	
Choose Card:	Credit [F1] Debit [F2]	Press F1 for credit.
Exp Date (MMYY):	Key in the expiration date in MMYY format and press ENTER .	
Password:	Key in the appropriate password and press ENTER .	
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press ENTER .	
[Account #] Confirm	Yes [F1] No [F2]	Press F1 if card number matches. Press F2 to cancel transaction.
Imprint Card Press Enter Key	Press ENTER .	
Cust Ref #:	Key in the customer reference number and press ENTER or press ENTER to bypass.	
Invoice #:	Key in the invoice number and press ENTER .	
Table #:	Key in table number and press ENTER or press ENTER to bypass.	
Server Id#:	Key in server ID and press ENTER .	
Logon:	Yes [F1] No [F2]	Press F1 to logon the server ID. Press F2 to return to idle prompt.
Password:	Key in the server password and press ENTER .	
Amount:	\$0.00	Key in the amount and press ENTER .
Tax Amt:	\$0.00	Key in the amount of the tax and press ENTER or press ENTER to bypass.
Tip:	\$0.00	Key in the amount of the tip and press ENTER or press ENTER to bypass.
Send Duplicate?	Yes [F1] No [F2]	Press F1 to send duplicate. Press F2 to cancel transaction.
Password:	Key in the appropriate password and press ENTER .	
V-Code:	Key in the CVC code from back of card and press ENTER or press ENTER to bypass.	
	No [F1] Code Present? Xread [F2]	Press F1 if code is not present. Press F2 if code is unreadable.
Address:	Key in the cardholder address and press ENTER or press ENTER to bypass.	
Zip Code:	Key in the cardholder ZIP code and press ENTER or press ENTER to bypass.	
Waiting for answer Please wait...	(No action while processing).	
\$X.XX Payment Type	Cash [F1] Credit [F2] Debit [F3] SV [F4]	Select payment type and press ENTER .

SALE (continued)		
TERMINAL DISPLAY	ACTION	
Print Cust Copy	No [F1] read [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .	
Tip Amount: New Tip:	Key in the tip amount and press ENTER or press ENTER to return to idle prompt.	
Amount Due: Enter to confirm	\$xx.xx	Press ENTER to begin sale trans. Press CANCEL to return to idle prompt.

AUTH ONLY		
TERMINAL DISPLAY	ACTION	
Idle prompt	Press ARROW twice.	
	Check [F1] Auth Only [F2] Phone Order [F3] Other Setup [F4]	Press F2 for Auth Only.
Password:	Key in the appropriate password and press ENTER .	
1= [Merchant 1]	Prev [F1] Next [F2] Slct [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .	
Swipe or enter account #:	Swipe card or key in the card number and press ENTER .	
Exp Date (MMYY):	Key in the expiration date in MMYY format and press ENTER .	
Password:	Key in the appropriate password and press ENTER .	
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press ENTER .	
[Account #] Confirm	Yes [F1] No [F2]	Press F1 if card number matches. Press F2 to cancel transaction.
Cust Ref #:	Key in the customer reference number and press ENTER or press ENTER to bypass.	
Invoice #:	Key in the invoice number and press ENTER .	
Table #:	Key in the table number and press ENTER or press ENTER to bypass.	
Server Id:	Key in the server ID number and press ENTER .	
Logon:	Yes [F1] No [F2]	Press F1 to logon the server ID. Press F2 to return to idle prompt.
Password:	Key in the clerk password and press ENTER .	
Amount	\$0.00	Key in the amount and press ENTER .
V-Code:	Key in the CVC code from back of card and press ENTER or press ENTER to bypass.	
	No [F1] Code Present? Xread [F2]	Press F1 if code is not present. Press F2 if code is unreadable.
Address:	Key in the cardholder address and press ENTER or press ENTER to bypass.	
Zip Code:	Key in the cardholder ZIP code and press ENTER or press ENTER to bypass.	

Shaded sections are optional or conditional prompts.

AUTH ONLY (continued)

TERMINAL DISPLAY	ACTION
Waiting for answer Please wait...	(No action while processing).
Print Cust Copy	Yes [F1] Press F1 to print customer copy. No [F2] Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .

FORCE SALE

TERMINAL DISPLAY	ACTION
Idle prompt	Press ARROW once.
	Refund [F1] Press F2 for Force. Force [F2] Tab [F3] Reprint [F4]
Password:	Key in the appropriate password and press ENTER .
1= [Merchant 1]	Prev [F1] Press F1 for previous merchant. Next [F2] Press F2 for next merchant. Slct [F3] Press F3 to select displayed merchant. Exit [F4] Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .
Swipe or enter account #:	Swipe card or key in the card number and press ENTER .
Choose Card:	Credit [F1] Press F1 for credit. Debit [F2]
Exp Date (MMYY):	Key in the expiration date in MMYY format and press ENTER .
Password:	Key in the appropriate password and press ENTER .
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press ENTER .
[Account #] Confirm	Yes [F1] Press F1 if card number matches. No [F2] Press F2 to cancel transaction.
Imprint Card Press Enter Key	Press ENTER .
Cust Ref #:	Key in the customer reference number and press ENTER or press ENTER to bypass.
Invoice #:	Key in the invoice number and press ENTER .
Table #:	Key in the table number and press ENTER or press ENTER to bypass.
Server Id:	Key in the server ID number and press ENTER .
Logon:	Yes [F1] Press F1 to logon the server ID. No [F2] Press F2 to return to idle prompt.
Password:	Key in the clerk password and press ENTER .
Amount	\$0.00 Key in the amount and press ENTER .
Tax Amt:	\$0.00 Key in the amount of tax and press ENTER or press ENTER to bypass.
Tip:	\$0.00 Key in the tip amount and press ENTER or press ENTER to bypass.
Send Duplicate?	Yes [F1] Press F1 to send duplicate. No [F2] Press F2 to cancel transaction.
Password:	Key in the appropriate password and press ENTER .
Appr Code:	Key in the authorization # and press ENTER .
Print Cust Copy	Yes [F1] Press F1 to print customer copy. No [F2] Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .

REFUND

TERMINAL DISPLAY	ACTION
Idle prompt	Press ARROW once.
	Refund [F1] Press F1 for Refund. Force [F2] Tab [F3] Reprint [F4]
Password:	Key in the appropriate password and press ENTER .
1= [Merchant 1]	Prev [F1] Press F1 for previous merchant. Next [F2] Press F2 for next merchant. Slct [F3] Press F3 to select displayed merchant. Exit [F4] Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .
Swipe or enter account #:	Swipe card or key in the card number and press ENTER .
Choose Card:	Credit [F1] Press F1 for credit. Debit [F2]
Exp Date (MMYY):	Key in the expiration date in MMYY format and press ENTER .
Password:	Key in the appropriate password and press ENTER .
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press ENTER .
[Account #] Confirm	Yes [F1] Press F1 if card number matches. No [F2] Press F2 to cancel transaction.
Imprint Card Press Enter Key	Press ENTER .
Cust Ref #:	Key in the customer reference number and press ENTER or press ENTER to bypass.
Invoice #:	Key in the invoice number and press ENTER .
Table #:	Key in the table number and press ENTER or press ENTER to bypass.
Server Id:	Key in the server ID number and press ENTER .
Logon:	Yes [F1] Press F1 to logon the server ID. No [F2] Press F2 to return to idle prompt.
Password:	Key in the server password and press ENTER .
Amount	\$0.00 Key in the amount and press ENTER .
Tax Amt:	\$0.00 Key in the amount of tax and press ENTER or press ENTER to bypass.
Send Duplicate?	Yes [F1] Press F1 to send duplicate. No [F2] Press F2 to cancel transaction.
Password:	Key in the appropriate password and press ENTER .
Print Cust Copy	Yes [F1] Press F1 to print customer copy. No [F2] Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .

DEBIT SALE

TERMINAL DISPLAY	ACTION
Idle prompt	Swipe debit card
Password:	Key in the appropriate password and press ENTER .
1= [Merchant 1]	Prev [F1] Press F1 for previous merchant. Next [F2] Press F2 for next merchant. Slct [F3] Press F3 to select displayed merchant. Exit [F4] Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .
Choose Card:	Credit [F1] Press F2 for debit. Debit [F2]
Cust Ref #:	Key in the customer reference number and press ENTER or press ENTER to bypass.
Invoice #:	Key in the invoice number and press ENTER .
Table #:	Key in the table number and press ENTER or press ENTER to bypass.
Server Id:	Key in the server ID number and press ENTER .
Logon:	Yes [F1] Press F1 to logon the server ID. No [F2] Press F2 to return to idle prompt.
Password:	Key in the server password and press ENTER .

Shaded sections are optional or conditional prompts.

DEBIT SALE (continued)		
TERMINAL DISPLAY	ACTION	
Amount	\$0.00	Key in the amount and press ENTER .
Tax Amt:	\$0.00	Key in the amount of tax and press ENTER or press ENTER to bypass.
Cashback:	\$0.00	Key in the cashback amount and press ENTER or press ENTER to bypass.
Tip:	\$0.00	Key in the tip amount and press ENTER or press ENTER to bypass.
Send Duplicate?	Yes [F1] No [F2]	Press F1 to send duplicate. Press F2 to cancel.
Password:	Key in the appropriate password and press ENTER .	
Enter PIN on pin pad	Customer keys PIN number on pin pad and presses ENTER .	
Waiting for answer Please wait...	(No action while processing)	
Print Cust Copy	Yes [F1] No [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .	

VOID		
TERMINAL DISPLAY	ACTION	
Idle prompt	Press F4 for Void.	
Password	Key in the appropriate password and press ENTER .	
1 = [Merchant 1]	Prev [F1] Next [F2] Sict [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .	
Void Last Trans?	Yes [F1] No [F2]	Press F1 to void last transaction. Press F2 to void other transaction.
Retrieve by:	Inv # [F1] Acct # [F2]	Press F1 to retrieve by invoice number. Press F2 to retrieve by account number.
Invoice Number:	Key in the invoice number and press ENTER .	
Last 4 Digits:	Key in the last 4 digits of the card number and press ENTER .	
[Account #] \$xx.xx	Yes [F1] No [F2] Next [F3]	Press F1 to void transaction. Press F2 to return to idle prompt. Press F3 to view next transaction.
Print Cust Copy	Yes [F1] No [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .	

REPRINT		
TERMINAL DISPLAY	ACTION	
Idle prompt	Press ARROW once.	
	Refund [F1] Force [F2] Tab [F3] Reprint [F4]	Press F4 for Reprint.
Password:	Key in the appropriate password and press ENTER .	
	REPRINT Last Receipt [F2] Any Receipt [F3]	Press F2 to print last receipt. Press F3 to print other receipt.
Invoice Number:	Key in the invoice number and press ENTER .	
Print Cust Copy	Yes [F1] No [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key	Press ENTER .	

OPEN TAB		
TERMINAL DISPLAY	ACTION	
Idle prompt	Press ARROW once.	
	Refund [F1] Force [F2] Tab [F3] Reprint [F4]	Press F3 for Tab.
Password:	Key in the appropriate password and press ENTER .	
	Tab Open Tab [F2] Close Tab [F3] Tab Report [F4]	Press F2 for open tab.
1 = [Merchant 1]	Prev [F1] Next [F2] Sict [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .	
Swipe or enter account #:	Swipe card or key in the card number and press ENTER .	
Exp Date (MMYY):	Key in the expiration date in MMYY format and press ENTER .	
Password:	Key in the appropriate password and press ENTER .	
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press ENTER .	
[Account #] Confirm	Yes [F1] No [F2]	Press F1 if card number matches. Press F2 to cancel transaction.
Imprint Card Press Enter Key	Press ENTER .	
Cust Ref #:	Key in the customer reference number and press ENTER or press ENTER to bypass.	
Invoice #:	Key in the invoice number and press ENTER .	
Table #:	Key in table number and press ENTER or press ENTER to bypass.	
Server Id#:	Key in server ID and press ENTER .	
Logon:	Yes [F1] No [F2]	Press F1 to logon the server ID. Press F2 to return to idle prompt.
Password:	Key in the server password and press ENTER .	
Amount:	\$0.00	Press ENTER to confirm default tab amount or key in amount and press ENTER .
Waiting for answer Please wait...	(No action while processing)	
Tear Receipt Press Enter Key	Press ENTER .	

CLOSE TAB		
TERMINAL DISPLAY	ACTION	
Idle prompt	Press ARROW once.	
	Refund [F1] Force [F2] Tab [F3] Reprint [F4]	Press F3 for tab.
Password:	Key in the appropriate password and press ENTER .	
	Tab Open Tab [F2] Close Tab [F3] Tab Report [F4]	Press F3 for tab.
1 = [Merchant 1]	Prev [F1] Next [F2] Sict [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:	Key in the merchant password and press ENTER .	
	Inv # [F1] Account # [F2]	Press F1 to close tab by invoice number. Press F2 to close tab by account number.
Retrieve by:		
Invoice #:	Key in the invoice number and press ENTER .	
Last 4 dgts Acct:	Key in the last 4 digits of the card # and press ENTER .	

Shaded sections are optional or conditional prompts.

CLOSE TAB (continued)

TERMINAL DISPLAY	ACTION	
[Account #] \$ x.xx	Yes [F1] No [F2] Next [F3]	Press F1 to close the tab displayed. Press F2 to cancel and return to the tab menu. Press F3 to scroll to the next transaction.
Cnfrm Same Card:	Yes [F1] No [F2]	Press F1 to close the tab on the same card. Press F2 to close the tab on a different card.
Cust Ref #:		Key in the customer reference number and press ENTER or press ENTER to bypass.
Table #:		Key in table number and press ENTER or press ENTER to bypass.
Server Id#:		Key in server ID and press ENTER .
Logon:	Yes [F1] No [F2]	Press F1 to logon the server ID. Press F2 to return to idle prompt.
Password:		Key in the server password and press ENTER .
Amount:	\$ x.xx	Key in amount and press ENTER .
New Amount:	\$ 0.00	
Tax Amount:	\$ 0.00	Key in amount of tax and press ENTER or press ENTER to bypass.
Tip:	\$ 0.00	Key in the tip amount and press ENTER or press ENTER to bypass.
Print Cust Copy	Yes [F1] No [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key		Press ENTER .

FORCE OPEN TAB

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW once.
	Refund [F1] Force [F2] Tab [F3] Reprint [F4]	Press F3 for tab.
Password:		Key in the appropriate password and press ENTER .
	Tab Open Tab [F2] Close Tab [F3] Tab Report [F4]	Press ARROW once.
	Force Open Tab [F1] Delete Tab [F2]	Press F1 to force open tab.
1= [Merchant 1]	Prev [F1] Next [F2] Slct [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:		Key in the merchant password and press ENTER .
Swipe or enter account #:		Swipe card or key in the card number and press ENTER .
Exp Date (MMYY):		Key in the expiration date in MMYY format and press ENTER .
Password:		Key in the appropriate password and press ENTER .
Last 4 dgts Acct:		Key in the last 4 digits of the card # and press ENTER .
[Account #] Confirm	Yes [F1] No [F2]	Press F1 if card number matches. Press F2 to cancel transaction.
Imprint Card Press Enter Key		Press ENTER .
Cust Ref #:		Key in the customer reference number and press ENTER or press ENTER to bypass.
Invoice #:		Key in the invoice number and press ENTER .
Table #:		Key in table number and press ENTER or press ENTER to bypass.
Server Id#:		Key in server ID and press ENTER .
Logon:	Yes [F1] No [F2]	Press F1 to logon the server ID. Press F2 to return to idle prompt.
Password:		Key in the server password and press ENTER .

FORCE OPEN TAB (continued)

TERMINAL DISPLAY	ACTION	
Amount:	\$0.00	Key in amount and press ENTER .
Appr. Code:		Key in the authorization number and press ENTER .
Print Cust Copy	Yes [F1] No [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key		Press ENTER .

DELETE TAB

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW once.
	Refund [F1] Force [F2] Tab [F3] Reprint [F4]	Press F3 for tab.
Password:		Key in the appropriate password and press ENTER .
	Tab Open Tab [F2] Close Tab [F3] Tab Report [F4]	Press ARROW once.
	Force Open Tab [F1] Delete Tab [F2]	Press F2 to delete tab.
1= [Merchant 1]	Prev [F1] Next [F2] Slct [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:		Key in the merchant password and press ENTER .
	Inv # [F1] Account # [F2]	Press F1 to close tab by invoice number. Press F2 to close tab by account number.
Retrieve by:		
Invoice #:		Key in the invoice number and press ENTER .
Last 4 dgts Acct:		Key in the last 4 digits of the card # and press ENTER .
	Yes [F1] No [F2] Next [F3]	Press F1 to close the tab displayed. Press F2 to cancel and return to the tab menu. Press F3 to scroll to the next transaction.
[Account #] \$ x.xx		
Tab Deleted		Terminal returns to the tab menu.

TIP ADJUSTMENT

TERMINAL DISPLAY	ACTION	
Idle prompt		Press TIP hot key.
Password:		Key in the appropriate password and press ENTER .
1= [Merchant 1]	Prev [F1] Next [F2] Slct [F3] Exit [F4]	Press F1 for previous merchant. Press F2 for next merchant. Press F3 to select displayed merchant. Press F4 to exit.
Merch Password:		Key in the merchant password and press ENTER .
	Srvr [F1] Amt [F2] Acct [F3] Inv # [F4]	Press F1 to retrieve by server. Press F2 to retrieve by amount. Press F3 to retrieve by account number. Press F4 to retrieve by invoice number.
Retrieve by:		
Server Id:		Key in the server ID number and press ENTER .
Amount:	\$ 0.00	Key in the amount and press ENTER .
Last 4 dgts Acct:		Key in the last 4 digits of the card # and press ENTER .
Invoice Number:		Key in the invoice number and press ENTER .
	Adj [F1] Prev [F2] Next [F3] Inv # [F4]	Press F1 to adjust the transaction. Press F2 to scroll to previous transaction. Press F3 to scroll to next transaction. Press F4 to exit.
[Account #] \$ x.xx		
Tip Amount: New Tip:	\$ x.xx \$ 0.00	Key in the new tip amount and press ENTER .

Shaded sections are optional or conditional prompts.

TIP ADJUSTMENT (continued)

TERMINAL DISPLAY	ACTION	
Print Cust Copy	Yes [F1] No [F2]	Press F1 to print customer copy. Press F2 to print only merchant copy.
Tear Receipt Press Enter Key		Press ENTER .
	Add [F1] Prev [F2] Next [F3] Exit [F4]	Press F1 to adjust the transaction. Press F2 to scroll to previous transaction. Press F3 to scroll to next transaction. Press F4 to exit.
[Account #] \$ x.xx		

SERVER MANAGEMENT - ADD SERVER

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW three times.
Server Setup [F1] Store/Forward [F2] HELP [F3]		Press F1 for Server Setup.
Password:		Key in the appropriate password and press ENTER .
CONFIGURE SERVER Log On Server [F2] Log Off Server [F3] Add Server [F4]		Press F4 to add server to terminal.
Password:		Key in the appropriate password and press ENTER .
Server ID:		Key in the ID number of the server and press ENTER .
Password:		Key in the new server password and press ENTER .
Reenter:		Key in the new password again for confirmation and press ENTER .
Server ID:		Prompt will continue to display until CLEAR is pressed to exit. Repeat for each server being added.

SERVER MANAGEMENT - LOG ON/OFF SERVER

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW three times.
Server Setup [F1] Store/Forward [F2] HELP [F3]		Press F1 for Server Setup.
Password:		Key in the appropriate password and press ENTER .
CONFIGURE SERVER Log On Server [F2] Log Off Server [F3] Add Server [F4]		Press F2 to log on server. Press F3 to log off server.
Server ID:		Key in the ID number of the server and press ENTER .
Password:		Key in the server password and press ENTER .
Confirm	Yes [F1] No [F2]	Press F1 to log on/off server. Press F2 to cancel.
Logoff/on is successful		Terminal displays confirmation of logon/off and returns to the idle prompt.

SERVER MANAGEMENT - CLEAR SERVER

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW three times.
Server Setup [F1] Store/Forward [F2] HELP [F3]		Press F1 for Server Setup.
Password:		Key in the appropriate password and press ENTER .
CONFIGURE SERVER Log On Server [F2] Log Off Server [F3] Add Server [F4]		Press ARROW for more options.

SERVER MANAGEMENT - CLEAR SERVER (continued)

TERMINAL DISPLAY	ACTION	
Modify Server [F1] Delete Server [F2] Clear Servers [F3]		Press F3 for Clear Servers.
Server t/s cleared		Terminal confirms that servers have been cleared and returns to the idle prompt.

SERVER MANAGEMENT - DELETE SERVER

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW three times.
Server Setup [F1] Store/Forward [F2] HELP [F3]		Press F1 for Server Setup.
Password:		Key in the appropriate password and press ENTER .
CONFIGURE SERVER Log On Server [F2] Log Off Server [F3] Add Server [F4]		Press ARROW for more options.
Modify Server [F1] Delete Server [F2] Clear Servers [F3]		Press F2 for Delete Server.
Password:		Key in the appropriate password and press ENTER .
Server ID:		Key in the ID number of the server and press ENTER .
Password:		Key in the server password and press ENTER .
Server ID:		Prompt will continue to display until CLEAR is pressed to exit. Repeat for each server being deleted.

SERVER MANAGEMENT - MODIFY SERVER

TERMINAL DISPLAY	ACTION	
Idle prompt		Press ARROW three times.
Server Setup [F1] Store/Forward [F2] HELP [F3]		Press F1 for Server Setup.
Password:		Key in the appropriate password and press ENTER .
CONFIGURE SERVER Log On Server [F2] Log Off Server [F3] Add Server [F4]		Press ARROW for more options.
Modify Server [F1] Delete Server [F2] Clear Servers [F3]		Press F1 for Modify Servers.
Password:		Key in the appropriate password and press ENTER .
Server ID:		Key in the ID number of the server and press ENTER .
Svr Password:		Key in the appropriate server password and press ENTER .
PWrd [F1] Tip [F2]		Press F1 to modify the server password. Press F2 to modify the server's cash tips.
Old Pass:		Key in the old server password and press ENTER .
New Pass:		Key in the new server password and press ENTER .
Reenter:		Key in the new password again for confirmation and press ENTER .
Cash Tip Amt: New Amt:	\$ x.xx \$ 0.00	Key in the server's cash tip amount and press ENTER or press ENTER to bypass.
Server ID:		Prompt will continue to display until CLEAR is pressed to exit.

Shaded sections are optional or conditional prompts.

SERVER MANAGEMENT - SERVER REPORTS

TERMINAL DISPLAY	ACTION
Idle prompt	Press REPORTS hot key.
Password:	Key in the appropriate password and press ENTER .
REPORTS Totals Report [F2] Detail Report [F3] Server Reports [F4]	Press F4 for Server Reports.
SERVER REPORTS Total Report [F2] Detail Report [F3] Shift Report [F4]	Press F2 for server totals. Press F3 for server detail. Press F4 for shift report. Press ARROW for more options.
Server Table [F1] Unadjst Report [F2] IRS Tip Report [F3] Discount Tip [F4]	Press F1 for server table. Press F2 for unadjustd trans. Press F3 for server IRS tip report. Press F4 for discount tips
Srvr Rpt Options One [F1] All [F2]	Press F1 for single server detail. Press F2 for all server detail.
Server ID:	Key in the ID number of the server and press ENTER .
Cash Tip Amt: \$ 0.00 New Amt: \$ 0.00	Key in the server's cash tip amount and press ENTER or press ENTER to bypass.
Server Report:	Report prints.

VIEWING BATCH TOTALS

TERMINAL DISPLAY	ACTION
Idle Prompt	Press REPORTS hot key.
Password:	Key in the appropriate password and press ENTER .
REPORTS Totals Report [F2] Detail Report [F3] Server Reports [F4]	Press ARROW key for more reports.
Batch Review [F1] Batch History [F2] Terminal Rpts [F3] Activity Log [F4]	Press F1 for batch review.
BATCH REVIEW Totals Review [F2] Detail Review [F3]	Press F2 for totals review.
1= [Merchant 1]	Prev [F1] Press F1 for previous merchant. Next [F2] Press F2 for next merchant. Slct [F3] Press F3 for select displayed merchant. Exit [F4] Press F4 to exit.
Merch Passwd:	Key in the merchant password and press ENTER .
Host: [Host]	Prev [F1] Press F1 for previous host. Next [F2] Press F2 for next host. Slct [F3] Press F3 for view totals for host displayed Exit [F4] Press F4 to exit.
Host: [Host] Sales: \$xx.xx Refunds: \$xx.xx Total: \$xx.xx	Press CLEAR to return to batch review main menu.

REPORTS

TERMINAL DISPLAY	ACTION
Idle Prompt	Press REPORTS hot key.
Password:	Key in the appropriate password and press ENTER .
REPORTS Totals Report [F2] Detail Report [F3] Server Reports [F4]	Press F2 for totals report. Press F3 for details report. Press F4 for server report Press ARROW for more reports.

REPORTS (continued)

TERMINAL DISPLAY	ACTION
Batch Review [F1] Batch History [F2] Terminal Rpts [F3] Activity Log [F4]	Press F1 for batch review. Press F2 for batch history. Press F3 for terminal reports. Press F4 for activity log. Press ARROW for more reports.
[Name of Report]	Report prints.

TAB REPORT

TERMINAL DISPLAY	ACTION
Idle Prompt	Press ARROW once.
Refund [F1] Force [F2] Tab [F3] Reprint [F4]	Press F3 for Tab.
Password:	Key in the appropriate password and press ENTER .
Tab Open Tab [F2] Close Tab [F3] Tab Report [F4]	Press F4 for Tab Report.
Open Tab	Report prints.

HOST TOTALS REPORT

TERMINAL DISPLAY	ACTION
Idle Prompt	Press REPORTS hot key.
Password:	Key in the appropriate password and press ENTER .
REPORTS Totals Report [F2] Detail Report [F3] Server Reports [F4]	Press ARROW twice.
Merchant Rpt [F1] Host Totals [F2] VCX Ext. Error [F3]	Press F2 for host totals.
Processing	(No action while report prints)

SETTLEMENT

TERMINAL DISPLAY	ACTION
Idle Prompt	Press F3 for settlement.
Password:	Key in the appropriate password and press ENTER .
Sales: \$xx.xx Refunds: \$xx.xx Total: \$xx.xx Enter to confirm	Confirm totals, press ENTER .
Sales: \$00.00	Key in the sales total and press ENTER .
Refunds: \$00.00	Key in the refund total and press ENTER .
Total: \$00.00	Key in the batch total and press ENTER .
Settle Neg Batch Yes [F1] No [F2]	Press F1 to settle neg. batch Press F2 to return to idle prompt
Password	Key in the appropriate password and press ENTER .
Waiting for answer Please wait...	(No action while processing)
Settlement Successful	Settlement report prints and terminal returns to idle prompt.

Shaded sections are optional or conditional prompts.

AVS RESPONSE CODES

VISA	DESCRIPTION
Y	Address and 5-digit ZIP match (domestic only)
A	Address matches, ZIP code does not
S	AVS not supported at this time (domestic only)
R	Issuer's authorization system is unavailable, try again later (domestic only)
U	Unable to perform address verification because either address information is unavailable or issuer does not support AVS (domestic only)
Z	Either 5-digit or 9-digit ZIP matches, address does not or not included in request
N	Neither the ZIP nor the address matches
B	Address matches, ZIP not verified
P	ZIP matches, address not verified
C	Address and ZIP code not verified due to incompatible formats
D	Address and ZIP code match (international only)
G	Address not verified for international transaction (international only)
I	Address not verified (international only)
M	Address and ZIP code match (international only)

MASTERCARD	DESCRIPTION
Y	Exact, all digits match, 5-digit ZIP code
A	Address matches, ZIP code does not
S	AVS not supported at this time
R	Retry, system unable to process
U	No data from issuer/authorization system
Z	5-digit ZIP code matches, but address does not
N	Neither the ZIP nor the address matches
W	For U.S. addresses, 9-digit ZIP code matches, but address does not, for address outside of U.S., the ZIP code matches, address does not
X	Exact, all digits match, 9-digit ZIP code

DISCOVER NETWORK	DESCRIPTION
Y	Address only matches
A	Address and 5-digit ZIP code match
S	AVS not supported at this time
U	Retry, system unable to process
Z	5-digit ZIP code matches, but address does not
N	Neither the ZIP nor the address matches
W	No data from issuer/authorization system
X	Address and 9-digit ZIP code match
T	9-digit ZIP code matches, but address does not

AMERICAN EXPRESS	DESCRIPTION
Y	Yes, address and ZIP code are both correct
A	Address only is correct
B	AVS not supported at this time
R	System unavailable, retry
U	The necessary information is not available, account number is neither U.S. nor Canadian
Z	ZIP code only is correct
N	Neither the ZIP nor the address matches

IMPORTANT "VoIP" NOTICE

**ONLY IP CREDIT CARD TERMINALS ARE ABLE TO SUPPORT "VOICE OVER IP" (VoIP).
DIAL-UP TERMINALS WILL NOT WORK WITH VoIP SINCE THEY REQUIRE A LANDLINE.**

Changes made to your telephone system, such as converting to digital telephone service or Voice Over Internet Protocol (VoIP), can adversely affect the ability of your credit card terminal to function properly. Dial-up terminals do not work through VoIP. You must use a landline for dial-up terminals to function properly. If a dual communication terminal is present, a router must be used in conjunction with a DSL/cable modem to obtain a high speed connection.

If you plan on making any changes to the telephone system at the location where your terminal is used or if you have any questions in regards to your current terminal's capabilities, please contact technical support at 800-632-1888.