



# NURIT - RETAIL

Nurit 2085, 2085Plus, 2060, 2070, 2080

Customer Service: 800-201-0461  
24-Hour Technical Support: 800-632-1888

## CREDIT CARD SALE

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Swipe the credit card or manually key in the account number and expiration date.
Credit...Sale Amount	Enter amount of sale (no need to press decimal).
Dialing, Processing, Approved	Terminal returns to original prompt, "Credit...Sale Account".

## CREDIT CARD SALE (WITH AVS OPTION)

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Swipe the credit card or manually key in the account number and expiration date.
Credit...Sale Amount	Enter amount of sale (no need to press decimal).
Enter ZIP Code	Enter customer's zip code (billing address).
Street Address	Enter number address only.
Dialing, Processing, Approved	Terminal returns to original prompt, "Credit...Sale Account".

## CREDIT CARD RETURN

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press the <b>RETURN</b> key.
Credit...Return Account	Swipe the credit card or manually key in the account number and expiration date.
Credit...Return Amount	Enter amount of return (no need to press decimal).
Dialing, Processing, Approved	Terminal returns to original prompt, "Credit...Sale Account".

## VOID

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press the <b>VOID</b> key. The following transactions can be voided: Credit Card Sale, Forced Sale, Return.
Credit...Void/Sale Account	Swipe the credit card, or manually key in the account number and expiration date.
Credit...Void/Sale Amount	Enter amount of void (no need to press decimal) and press <b>ENTER</b> .
Approved Off Line	Terminal returns to original prompt, "Credit...Sale Account".

## FORCED CREDIT CARD SALE

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press the <b>FORCED</b> key.
Credit...Forced Account	Swipe the credit card or manually key in the account number and expiration date.
Credit...Forced Amount	Enter amount of sale (no need to press decimal).
Enter Auth. No	Enter authorization number
Approved Off Line	Tear slip and have customer sign receipt.

## BATCHING/SETTLEMENT

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press the <b>BATCH</b> key.
Choose Host: 1. All	Make selection by pressing <b>ENTER</b> .
Dialing...18005559999	Terminal will print detailed batch report.



# NURIT - RETAIL

Nurit 2085, 2085Plus, 2060, 2070, 2080

## COPY OF TRANSACTION RECEIPT

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press the <b>ALPHA</b> key.
Receipt Copy: 1. Last Receipt (2. Any Receipt)	Use the <b>FORCED</b> key to scroll through options. Make selection by press ENTER. If 1 is selected, terminal will print copy of last receipt. If 2 is selected, terminal will display.
Choose EDC Type: 2. Credit (3. Check) <small>This will vary depending on the EDC types available.</small>	Press <b>ENTER</b> to make selection.
Transaction #	Enter transaction number and press <b>ENTER</b> .

## PRINT A REPORT

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press the <b>REPORT</b> button.
Enter Password	Enter terminal password. Report prints.

## DEBIT SALE

TERMINAL DISPLAY	ACTION
Credit...Sale Account	Press <b>ENTER/PAYMT</b> .
Debit...Sale Account	Swipe the debit card (debit cards can't be manually entered unless they have a VISA/MC logo in which case they can be put through as a credit card sale).
Debit...Sale Amount	Enter amount of sale (no need to press decimal) and press <b>ENTER</b> .
If your terminal has cash back enabled, you will see: Cash Back 0.00 Total \$__.	Enter the amount of cash back and press <b>ENTER</b> .
Enter your P.I.N.	The customer enters their PIN number on the terminal or external PIN pad.
Dialing, Processing, Approved	Terminal returns to original prompt, "Credit...Sale Account".

### IMPORTANT "VoIP" NOTICE

**ONLY IP CREDIT CARD TERMINALS ARE ABLE TO SUPPORT "VOICE OVER IP" (VoIP).  
DIAL-UP TERMINALS WILL NOT WORK WITH VoIP SINCE THEY REQUIRE A LANDLINE.**

Changes made to your telephone system, such as converting to digital telephone service or Voice Over Internet Protocol (VoIP), can adversely affect the ability of your credit card terminal to function properly. Dial-up terminals do not work though VoIP. You must use a landline for dial-up terminals to function properly. If a dual communication terminal is present, a router must be used in conjunction with a DSL/cable modem to obtain a high speed connection.

If you plan on making any changes to the telephone system at the location where your terminal is used or if you have any questions in regards to your current terminal's capabilities, please contact technical support at 800-632-1888.